

Detail




Diagram A




Diagram B




Diagram C




Diagram D

1. Install suspended proprietary ceiling grid system with furring channels positioned to suit soundform panel sizes. Note - Max 600mm centres.
2. Screw fix lengths of 2400 x 90 x 12mm MDF soundfix slats at 600mm centres perpendicular to furring channels. See diagram A. NOTE – Screw heads must be countersunk.
3. Screw fix lengths of 590 x 40 x 12mm MDF soundfix slats (5mm from panel edges) to the rear of individual soundform panels. See diagrams B & D. Note - Screw heads must be countersunk.
4. Correctly position the soundform panels against the soundfix slats. Screw fix through the perforations/slots and the 40mm batten into the 90mm soundfix slats. Use black screws to reduce visibility of the screw heads against the black soundspun acoustic fabric. See diagram C.
5. Apply insulation above soundform panels as required.

Call 1300 760 146 for assistance or clarification





Diagram A




Diagram B

1. Install suspended proprietary ceiling grid system with furring channels positioned to suit soundform panel sizes. Note - Max 600mm centres.
2. Screw fix lengths of 2400 x 90 x 12mm MDF soundfix slats at 600mm centres, perpendicular to furring channels. See diagram A. NOTE – Screw heads must be countersunk.
3. Correctly position the soundform panels against the soundfix slats and screw fix from above through the soundfix slats into the rear of the soundform panels. See diagram B.
4. Apply insulation above soundform panels as required.

Call 1300 760 146 for assistance or clarification







Diagram A




Diagram B

1. Screw fix 595mm split battens to rear of soundform panel. See diagram A.  
*Tip- When setting out split battens allow a minimum of 15mm above the top panel to allow clearance to attach or remove panels.*
  2. Screw-fix 2400mm split battens into studs within walls. Pack out wall split batten as required. See diagram B.
  3. Apply insulation between split battens as required. See diagram B.
  4. Mount the soundform panels - starting with the lowest split batten working upwards.
- Call 1300 760 146 for assistance or clarification

